



# Keyfree 100

## Combination Lock Instructions

## Setting your combination lock

### STEP 1: Default Code Check

The lock is preset at the factory to “0-0-0-0.”

If this is your first time setting the code, turn the dials to “0-0-0-0.”

If the code has already been changed, enter the current code instead.

### STEP 2: Engage Code Setting Mode

Press and hold the code-setting button firmly.



### STEP 3: Set Your Desired Code

While holding the button, turn the dials to your preferred combination.

Release the button once the desired code is set.

### STEP 4: Secure the Lock

Scramble the dials to lock the mechanism.



## Resetting a lost code

### STEP 1: Open the Lock with the Master Key

Insert the master key into the lock and turn it 90 degrees to the right.

### STEP 2: Discover the Code

With the key turned, spin the dials downwards, top to bottom.

Each dial will stick at the correct number.

Continue until all four dials stick. The numbers displayed are the current code.

### STEP 3: Reset the Code

Once you have the code, reset it by following the steps in the “Setting Your Combination Lock” section above.

